

CLASSIC™ SERIES

LED UV-A Handheld Lamps



Classic Series consisting of 3 handheld LED lamps bridging the gap between the Vintage & uVision product lines. **ASTM E3022** Compliant with two available light configurations. The lamp handle is ergonomically designed and features a fan-less cooling system. The Classic Series lamps are ideal for fluorescent magnetic particle inspection, liquid penetrant testing and other specialized applications.

Features

- **Long-lasting UV-A lenses** - equipped with UV-A pass filter
- **Pistol Grip** - comfortable, balanced control
- **Anodized Aluminum Housing** - minimizes corrosion and stands up to years of heavy use
- **Rocker Switch** - easy on/off operation with rear rocker switch
- **Rubber Bumper** - protects LED's from damage

Part Number	ASTM E3022	ISO 3059	Airbus ATM6 Pratt & Whitney	Nominal Steady-State UV-A Intensity at 15 in (38 cm)	UV-A Coverage at 15 in (38 cm) at minimum 1,200 µW/cm2	Power Source	Light Source	Run Time/ Charge Time	White Light	Adapters
CLA-100	X	X		5,700 µW/cm ²	6 in (15 cm) Ø	AC 9 Ft Corded	2 UV-A LED's & 1 White LED	--	Y	A/B, C/F
CLA-100Z	X	X		5,700 µW/cm ²	6 in (15 cm) Ø	AC/DC (Li-ion Battery) Cordless	2 UV-A LED's & 1 White LED	7-8 hrs/ 2 hrs	Y	A/B, C/F, I, G, N, I w CCC Conf.
CLA-150	X	X		8,000µW/cm ²	7.5 in (19 cm) Ø	AC 9 Ft Corded	4 UV-A LED's	--	N	A/B, C/F, I, G, N

Specifications	Value
Lamphead Diameter	4.4 in (11.18 cm)
Length	6.7 in (17 cm)
Width	3.4 in (8.6 cm)
Height	7.45 in (18.9 cm)
Power Requirements	90 - 270 VAC, 50 to 60 Hz

