

## TRITAN™ 365 SERIES

LED UV-A Handheld Lamps



**TRITAN™ 365 SERIES** NDT lamps are Spectro-UV's signature inspection lamps, and are used around the world for reliable inspections. TRITAN™ lamps feature three hi-lux UV-A (365 nm) LEDs for fluorescent inspection, plus a convenient white light LED to locate surface flaws and illuminate dark work areas. Their broad-beam configuration provides an extremely wide coverage area, while a compact head design allows access into areas inaccessible to larger UV inspection lamps.



### Key Features

- **Three High-Flux UV-A LEDs (365 nm)** - Superior fluorescent inspection capability with broad-beam coverage
- **Integrated White Light LED** - 400 foot-candles for surface flaw detection and workspace illumination
- **Multiple Intensity Options** - Standard ( $\leq 5,000 \mu\text{W}/\text{cm}^2$ ) and high intensity (up to  $9,000 \mu\text{W}/\text{cm}^2$ ) configurations
- **Industry Standards** - Meets ASTM E3022, EN ISO 3059 and Rolls-Royce RRES 90061 specifications
- **Certificate of Conformance** - Validation report included with each lamp
- **Built-in Cooling System** - Integrated fan maintains optimal performance during extended use
- **Thermal Protection** - Cut-off circuitry prevents compliance issues from overheating on select models
- **Durable Construction** - Rubber bumper with Borosilicate glass lens protects LEDs
- **Flexible Power Options** - AC-powered and battery-operated models available
- **Extended Runtime** - Battery models provide 7 hours continuous operation

Part Number	ASTM E3022	ISO 3059	RRES-90061	AIRBUS ATM6	PRATT & WHITNEY	Nominal Steady-State UV-A Intensity at 15 in (38 cm)	UV-A Coverage at 15 in (38 cm) at minimum 1,200 $\mu\text{W}/\text{cm}^2$	Power Source	Run Time	White Light	Adaptors
<b>TRI-365SBLC</b>	X	X	X	X	X	4,500 $\mu\text{W}/\text{cm}^2$	5.5 in (14 cm) $\emptyset$	AC Cord	—	Y	A/B, C/F, I, G
<b>TRI-365HC</b>	X					8,000 $\mu\text{W}/\text{cm}^2$	6 in (15 cm) $\emptyset$	AC Cord	—	Y	A/B, C/F, I, G, A/B & F w 20 ft cord
<b>TRI-365HB</b>						9,000 $\mu\text{W}/\text{cm}^2$	6.5 in (16.5 cm) $\emptyset$	AC Cord	—	Y	A/B, C/F, I, G, A/B & F w 20 ft cord
<b>TRI-365DB</b>						4,750 $\mu\text{W}/\text{cm}^2$	5.5 in (14 cm) $\emptyset$	AC Cord	—	Y	A/B, C/F, I, G
<b>TRI-365MDB</b>						<5,000 $\mu\text{W}/\text{cm}^2$	5.5 in (14 cm) $\emptyset$	AC/DC (Li-Ion Battery)	7 hrs	Y	A/B, C/F, I, G
<b>TRI-365MHB</b>						9,000 $\mu\text{W}/\text{cm}^2$	6.5 in (16.5 cm) $\emptyset$	AC/DC (Li-Ion Battery)	7 hrs	Y	A/B, C/F, I, G

# TRITAN™ 365 SERIES

## LED UV-A Handheld Lamps

Available in multiple configurations including standard intensity, high intensity and fully compliant versions, the **TRITAN™ 365 Series** meets rigorous international standards including ASTM E3022, EN ISO 3059 and Rolls-Royce RRES 90061. The series offers both AC-powered and portable battery-operated models to accommodate diverse inspection environments and operational requirements.



**127955**  
Standard Faceplate



**128196**  
Faceplate with Integral UV-A pass filters (SBLC and HC models only)

### TRITAN™ 365 M-Series:

Portable, battery-operated AC/DC lamp kits. Includes UV-A lamp, rechargeable Li-Ion battery pack, power supply adapter with AC and DC cord sets, smart AC charger, UV-absorbing spectacles and padded carrying case

Specification	Details
<b>Light Source</b>	(3) UV-A LEDs, (1) white light LED
<b>Lamp Style</b>	Pistol Grip
<b>Lamp Head Diameter</b>	3.25 in (8.25 cm)
<b>Height</b>	8 in (20.3 cm)
<b>Weight</b>	1 lb (454 g)
<b>White Light LED Intensity</b>	400 foot-candles (4,306 lux)
<b>Power Requirements</b>	100-120VAC / 12VDC (Also available in 230 V & 240V Versions)
<b>Battery Pack</b>	Type: 14.8V, Li-Ion (rechargeable) Run time: 7 hours continuous Charge time: 4 hours
<b>Cooling System</b>	Built-in fan

**SPECTRO-UV®**

[www.Spectro-UV.com](http://www.Spectro-UV.com)

4 Dubon Ct., Farmingdale, NY 11735  
866-230-7305